Pre- and Post-Trip Vehicle Condition Report

Instructions: Drivers should perform necessary inspection. A 3 indicates satisfactory condition. An indicates unsafe or improper conditions. An indicates that a condition does not apply. Corrected deficiencies should be circled by management certifier.

1.	Inside ☐ Parking Brake (Apply)			
2.	Start Engine ☐ Oil pressure (light or gauge) ☐ Air pressure or vacuum (gauge) ☐ Low air or vacuum warning device (If air pressure is below 40 psi, check on pressure buildup. If air pressure is above 60 psi, deplete air until warning device works. If vacuum has below 8 inches Hg, check on buildup. If it has above 8 inches Hg, deplete vacuum until device works.) ☐ Instrument panel (Telltale lights, buzzers, gauges) ☐ Horn, windshield wiper and washer ☐ Heater-defroster ☐ Mirrors ☐ Steering wheel (excess play) ☐ Apply trailer brakes in emergency ☐ Turn on all lights including 4-way flasher ☐ Make sure engine starts properly			
3.	On Combinations ☐ Hoses ☐ Connections ☐ Couplings (Fifth wheel, tow bar, safety chains, locking devices)			
4.	Emergency Equipment Fire extinguishers Flags Standards Warning lights Spare fuses Spare bulbs Chains in season First aid kit			
5.	Front ☐ Headlights ☐ Clearance lights ☐ Identification lights ☐ Turn signs and 4-way flasher ☐ Tires and wheels-lugs and serviceability			
6.	Inside ☐ Release trailer emergency brakes ☐ Apply service brake (Air loss should not exceed 3 psi per minute on single vehicles, 4 psi per minute on combinations.)			

Drivers should consider the following when completing a thorough inspection of the vehicle's condition before and after each trip.



7.	Side Left		Fuel tank and cap Sidemarker lights Reflectors Tires and wheels-lugs and serviceability Cargo tie-downs and/or doors		
8.		Tail lights Stop light Turn Signals and 4-way flasher Clearance lights Identification lights Reflectors Tires and wheels			
9.	Mec	chanical Operation Engine – knocks, misses, overheats, etc. Clutch – skips, grabs, other			

The information presented in this publication is intended to provide guidance and is not intended as a legal interpretation of any federal, state or local laws, rules or regulations applicable to your business. The loss prevention information provided is intended only to assist policyholders in the management of potential loss producing conditions involving their premises and/or operations based on generally accepted safe practices. In providing such information, Great American does not warrant that all potential hazards or conditions have been evaluated or can be controlled. It is not intended as an offer to write insurance for such conditions or exposures. The liability of Great American Insurance Company and its affiliated insurers is limited to the terms, limits and conditions of the insurance policies underwritten by any of them.

The Great American Insurance Group eagle logo and the word marks Great American® and Great American Insurance Group® are registered service marks of Great American Insurance Company. © 2020 Great American Insurance Company. All rights reserved. Great American Insurance Group, 301 E. Fourth St., Cincinnati, OH 45202. F13641A-LP (10/20)

